

### Instruction of Install LAN Adapter Driver

- Put into the CD
- Double-click the CD drive letter, choose the corresponding model No., then click "Install".
- Accept and click "Next"
- Choose the installation type, and click "Next"
- Choose TOTOLINK or Windows wireless LAN adapter configuration program, and click "Next".
- Click "Install"
- Click "Finish", the driver program is installed successfully.

### TOTOLINK The Smartest Network Device

## Quick Installation Guide

### Wireless N Dual Band USB Adapter

Copyrights 2014 by TOTOLINK All rights reserved. Website: <http://www.totolink.net>  
Information in this document is subject to change without prior notice.

### LAN Adapter Windows Search Connection No Encryption Network Diagram

- Right-click "My Network Places", and choose "Properties"
- Right-click "Wireless Network Connection", choose "View available wireless connection"
- Choose a wireless network
- When the wireless network is connected, then you can access Internet.

Confirm the SSID name of wireless network, choose the wireless network which you would like to connect and click "Connect"

Switch wireless LAN Adapter configuration program

Wireless LAN adapter provides two wireless LAN adapter connection configuration programs, one is TOTOLINK wireless LAN adapter connection configuration program, another is Windows wireless LAN adapter connection configuration program.

### LAN Adapter Physical Connection Diagram

- Connect the adapter to the USB3.0 Port of your computer with the provided USB cable.

Note: Computer found the wireless LAN adapter hardware, have to install the driver.

### LAN Adapter Windows Search Connection WEP Encryption Network Diagram

- Right-click "My Network Places", and choose "Properties"
- Right-click "Wireless Network Connection", choose "View available wireless connection"
- Choose a wireless network
- Input WEP secret key, click "Connect"
- When the wireless network is connected, then you can access Internet.

Confirm the SSID name of wireless network, choose the wireless network which you would like to connect and click "Connect"

### LAN Adapter Windows Search Connection WPA/PSK Encryption Network Diagram

- Right-click "My Network Places", and choose "Properties"
- Right-click "Wireless Network Connection", choose "View available wireless connection"
- Choose the wireless network which you would like to connect and click "Connect"
- Input WPA/PSK secret key, click "Connect"
- Have connected the wireless network.

### TOTOLINK LAN Adapter Configuration Tool Search Connection Network Diagram

- Click this icon and the wireless connection configuration windows will pop up. You can find 2.4GHz & 5GHz band signal by the adapter.
- Connect WPA-PSK Encryption Wireless Network Steps:
  - Choose the wireless network which you would like to connect, and then click "Connect"
  - Choose the secret key type in the pop-up window, input the WPA pre-shared key, and then click "OK"
  - Wireless network is connected
- Connect No Encryption Wireless Network Steps:
  - Choose the wireless network which you would like to connect, and then click "Connect"
  - Wireless network is connected

### Win 7/Vista Windows 7/Vista Connection Network Diagram

#### Connect to Encryption Network (WEP / WPA/PSK)

- Right-click "Network", choose "Properties"
- Click "Connect to a network"
- Click "Connect"
- Finish

#### Connect to No Encryption Network

- Click "Connect to a network"
- Click "Connect"
- Finish